



1. Slide **RockGuard** between windshield and nose of sprayer (fig.1).
2. Unbolt nuts on either side of windshield, and replace with grommets and strap tab on center top of **RockGuard** (fig.2).
3. Unzip side pockets on **RockGuard** and re-zip around windshield side handrails.
4. Snap hooks on either side of windshield wiper through grommets at center of **RockGuard** (fig.3).
5. Tighten straps at all four corners – on top around mirror brackets, and on bottom through holes in platform (fig.4).
6. **RockGuard** can be left installed while spraying, by rolling it up and fastening it to the opposite door front pillar, or it can be taken off altogether (fig.5).

Warranty Validation Form

To validate your 1 year warranty against defects in workmanship, please fill out and mail to Signature Cover, Box 10, 135 Elm Park Rd., Elm Creek, MB, Canada, R0G 0N0.

NAME: _____ ADDRESS: _____

PURCHASE DATE: ___/___/___ DEALER: _____

PRODUCT: _____

